



## 10. How to use label

- The label simulates the clock dial. You may put like this if you like (see image).



The label can be put like this if you like.


## 11. Connection with DCC device and its operation

This subject shall be handled by upper users.


- This product can be connected with DCC devices.
- The decoding address assigned to this Turntable is fixed as "200" which is not changeable.
- Turnout function button on DCC controller will be assigned to this job.
- Even when <DCC reverse loop module> is used, there is some chance to have short circuit if its tuning dial is not at suitable position. Rokuhan train controller recognizes it and stops running train. Turntable controller also recognizes it and stops turning turntable. To resume normal function, please read the instruction manual of DCC reverse loop module and adjust tuning properly.

\* We do not guarantee to connect this Turntable with all DCC devices.


## 12. Related Rokuhan products



A035 Turntable rail block



A036 Turntable extension cable



S038 Round house

## 13. Trouble shooting

- The short-circuit happens and train stops when it across the Gap joiner  
⇒Power-off first, then adjust the condition based on "8.How to operate" and power-on again.
- Train is derailed due to deviation of tracks.  
⇒Push Adjust button and modify deviation of each track.
- Turntable does not turn due to hitting with rail block.  
⇒Check rail block condition to set it at proper location, then re-start operation.

## 14. Trouble and repair

- The user is responsible for any trouble, accident, or injury caused by misuse, disassembling, or modification of this product. Rokuhan will not repair a product which has been opened, taken apart, or modified.
- Specification and appearance of our products are subject to change without prior notice.
- We sell assembled product only.
- Contact Rokuhan customer service if you have any questions about this product.



TOYTEC CORPORATION

7-27, NUMAWADA, TOCHIGI-CITY, 328-0042, JAPAN.

TEL : 81-282-20-2365

URL : <http://www.rokuhan.com/english/>