

Thank you for purchasing this Rokuhan product. This is precise train model, so please handle carefully.
Please read this instruction manual carefully first before operation.

1. Caution

- Use only a Rokuhan controller to operate this product.
- Clean track surface (Metal rails) before operation.
- Remove dirt and dust from wheels.
- Do NOT operate continuously over a long period of time.
- In the case of derailment or short circuit, power off controller switch, unplug the AC adapter, and then eliminate the cause of problem.
- Disassembling and modification could cause failure of this product.
- Storing this product in direct sunlight or fluorescent light for a long time could cause change in color.
- Store and operate this product in dust free locations, away from sources of heat.
- To avoid shock or electrocution, do not operate this product in a wet location or operate with wet hands.
- This product includes sharp edge parts. Handle with care.
- Handle tools with care.
- This product is NOT recommended for use by children under 15 years old unless supervised by an adult.

2. Parts list

① DD51 1 pc (Only for T002-10)
..... 2 pcs (Only for T002-9)

② Runner parts
Black 4 pcs, Silver 1 pc (only for T002-9)
Black 2 pcs, Silver 1 pc (only for T002-10)

[(1) Cover plate (3) Arnold coupler (Long)
(2) Dummy coupler (4) Knuckle coupler


③ Flagpole 1 pc ⑤ Head mark (only for T002-9) 2 pcs
④ Flag label sheet 1 pc ⑥ Instruction manual 1 pc

3. How to install accessory parts

3-1. Change couplers

- For double heading formation of DD51, Arnold coupler (Long) should be applied to avoid derailment to run on curved tracks with small radius.


1. Holding DD51 by finger, then pull out Arnold coupler (Short). (See figure 1)



2. Remove couplers from runner by side cutter, then insert them in place.


- How to set Dummy coupler

Insert Dummy coupler into place [1], then insert Cover plate into place [2]. (See Figure 2)



- How to set European coupler (sold separately, A022), Knuckle coupler & Arnold coupler (Long).


Insert each coupler into place [2]. (See figure 3)



* Make sure each coupler is inserted with correct side properly.

3-2. How to set Flagpole and Flag label


1. Peel-off the Flag label and stick it around the flagpole.
2. Pull out Arnold coupler (See figure 1)
3. Insert Dummy coupler (See figure 2)
4. Insert the Flagpole between Dummy coupler & Body.



3-3. How to set Head mark (only T002-9)

Set Head mark in the center of Handrail (See figure 4)

* Please pay attention NOT to break Handrail when applying Head mark.



4. Maintenance

4-1. Maintenance

- If this product does not work, make sure feeder cable and power are plugged in place properly, then the positions of main switch and direction selector on controller should be checked. Also please make sure batteries for controller are set in place if using without AC adapter.
- The metal wheels and tracks may be dirty if this product does not run smoothly. Please remove the dirt on the metal wheels and tracks with a clean cloth and rail cleaner.
* Do NOT put excessive power on the wheels when cleaning them up.
- This product is precise model. Please pay attention NOT to damage, drop or put excessive pressure. Handle it with care.

4-2. Handrails

This product have "Handrails" at front/rear area which are made by precise etching parts.

Do NOT damage, drop or put excessive pressure on it.

5. Trouble and repair

- Any trouble, accident, or injury caused by misuse, disassembling, and modification of this product are subject to no responsibility by Rokuhan. And Rokuhan do NOT accept repair requests of any products which have been disassembling or modifications.
- Product specification and appearance are subject to change without prior notice.
- Available only completed product.
- Take contact Rokuhan customer service if you have any questions about this product.