7. Lightning accessories (Sold separately)

7 − 1 Room light <Able to install in all cars>

This lighting accessories can use in all cars. (Either A009 or A030 can be used)

Please read each instruction manual included with each lighting parts.

7-2 DCC Decoder <A059 able to install in all cars>

Trim a part of DCC decoder to fit, trim with nippers to install in every type of car with A059. DCC DECODER MULTIPUL TYPE. (See Figure 17) Please read included instruction manual of A059 for more information.

A009 Room light type A

Figure 17 T031-1 489 limited express "HAKUSAN" HAKUSAN color 5 cars basic set

A030 Room light for front/tail car (short) A059 DCC Decoder room light multi type (Room light C type mode) A059 DCC Decoder room light multi type (Room light A type mode) M €/\488-205

T031-2 489 limited express "HAKUSAN" HAKUSAN color 4 cars extension set


A009 Room light type A

A059 DCC Decoder room light multi type (Room light A type mode)

*Please open car as shown when installing room light or decoder. (See Figure 18)

Related cars…クハ489-505 ウハ489-5

*After installing room light, or decoder, turn chassis upside down to install in body as shown.



8. Trouble shooting

Check following before ordering repair.

Problem	Cause	Correction		
Trains do not run smoothly.	There is dirt on rails.	Remove the dirt with cleaner and cloth.		
Or lights flicker.	There is dirt on wheels.	Remove the dirt with cleaner and cloth.		
Trains do not run.	A train derails.	Set the train properly on track using relailer.		

9. Trouble and repair

- The user is responsible for any trouble, accident, or injury caused by misuse, disassembling, or modification of this product by himself. Rokuhan will not have any responsibility of repair a product which has been opened.
- Specification and appearance of our products are subject to change without prior notice.
- •We sell completed product only.
- Take contact Rokuhan customer service if you have any questions about this product.



7-27, NUMAWADA, TOCHIGI-CITY. 328-0042, JAPAN.

TEL: 81-282-20-2365




489 Limited Express "HAKUSAN" HAKUSAN Color Common instruction manual

Thank you for purchasing this Rokuhan product.

This product is precision product. Please read this instruction manual carefully before operation and operate properly.

Caution

- Please operate this model with a Rokuhan controller.
- Clean up tracks (metal rails) before operation.
- Remove dirt and dust on wheels.
- Do not operate continuously over a long period of time.
- Do not change train direction suddenly. Stop train first then change direction.
- ●In the case of derailment or short circuit, turn off the power of controller immediately, unplug the controller, and then eliminate cause of problem.
- Disassembling and modification work could cause damage to this product.
- Storing this product under sunlight or fluorescent light for a long time could cause discoloration.
- Keep this product away humidity, dust and heating devices.
- ●To avoid shock or electrocution, do not operate this product in wet place or touch with wet hands.
- To avoid injury with sharp parts, please handle with care.
- This product is not recommended that children under 15 years old use unless supervised by an adult.
- Keep train cars in Poly bag, to avoid damage after using.



2. Parts list

T031-1 489 LIMITED EXPRESS "HAKUSAN" HAKUSAN COLOR 5 CARS BASIC SET

Cars

クハ489-505

サロ489-25


M ±11488-205

±/\489-20

クハ489-5

Accessory parts

±/\488-215







±/\489-13



- (1) Runner parts A····2plates(1pc for spare) (2) Runner parts B····3plates (Antenna A.B. 4pcs for each Antenna (Head mark 3kinds 2pcs for each) C...8pcs)
- 3 Replacement coupler for connection ... 1pc 4)Instruction manual · · · · · 1pc Instruction manual (Japanese) 1pc

T031-2 489 LIMITED EXPRESS "HAKUSAN" HAKUSAN COLOR 4CARS EXTENSION SET

±/\488-13

Cars

±/\489-30



Accessory parts


1)Instruction manual ······1pc Instruction manual (Japanese) · · · · 1pc


TOYTEC CORPORATION URL: http://www.rokuhan.com/english/

3. How to handle accessories

3-1 Pantograph Related cars···モ/\488

1 Lift-up top part softly by thinner rod or needle until stop. (See Figure 1)







Please adjust the position as shown.

*Pantograph will be broken if pulled down too hard.

②Push down top part slowly and softly with thin rod or needle until stop. (See Figure 2)





Please adjust the position as shown.

*Pantograph will be broken if pulled down too hard.

Switch

3-2 Switch off head/tail lights

Related cars…クハ489


Please check the bottom chassis to move the slide switch to the off position. (See Figure 3)



Related cars…クハ489

Please cut out the Head mark from Runner B.

1)Turn upside down and remove chassis from body shell to diagonally upward. (See Figure 4)



3 Take out original headmark by tweezers or suitable tools. Set new headmark in reverse order and push in until seated. (See Figure 6)




3-4 Replacement of coupler

Related cars…クハ489-505

For connect 7/1489-505 with other cars.

1 Take out dummy coupler by pull and down. (See Figure 8)



4)Set chassis into body shell in reverse order.

2) Push head mark inside by rod or needle from outside.

(See Figure 5)


Figure 5

mark out

Thin rod or

(See Figure 7)


2 Set connection coupler into body by reverse procedure. (See Figure 9)



4. How to set parts

Set Antenna C on T031-1

Please set Antenna C into the hole. (See Figure 10)



5. How to install antenna (for expert user)

This process is for expert users who understand this model well. Please be careful to handle tools to avoid injury and work carefully.

Also, DIA 1.0mm drill and tweezers are necessary to set small antenna.


This product has no hole for wireless or telephone antenna. If you like to set antenna for your preference, please follow this instruction as below.

Related cars…クハ489*サロ489

5-1 Set Antenna A on T031-1 <クハ489>

1)Take out chassis from body shell of クハ489. Turn over, find the drilling place and make DIA0.1mm 2 Set antenna A part into the hole. (See Figure 12)

hole. (See Figure 11)




5-2 Set Antenna B on T031-1 <サロ481>

1) Take out chassis from body shell of サロ481. Turn over, find the drilling

place and make DIA0.1mm ②Set antenna A part into the hole. hole. (See Figure 13)

(See Figure 14)





6. Formation

Please set "HAKUSAN" full organization 9 cars T031-1 and T031-2. (See Figure 15)

Figure 15 ←Ueno•Kanaza	iwa			\diamond \diamond		\diamond \diamond		Naoetsu→
クハ489-505	±/\488-215	モハ489-30	サロ489-25	M±/\488-205	モ/\489-20	₹/\488-13	モハ489-13	クハ489-5
Basic set (T031-1)	Extension set (T031-2)	Extension set (T031-2)	Basic set (T031-1)	Basic set (T031-1)	Basic set (T031-1)	Extension set (T031-2)	Extension set (T031-2)	Basic set (T031-1)

Make another formation which operated at Shinetsu Line with EF63 Electric locomotive. (See Figure 16)

Figure 16	*EF63 Electric locomotive will be released on 2021.
←Yokokawa	Karuizawa→
EF63 EF63 7/\489-505 \ \(\frac{1}{\pi} \cdot \lambda \rightarrow	30 サロ489-25 1 サロ488-205 モハ489-20 モハ488-13 モハ489-13 クハ489-5