# 6. Accessories (sold separately)

#### 6-1. Room lights

Compatible models: All cars

Room lights, sold separately, can be installed in all cars. (See figure 7) A015 (ROOM LIGHT TYPE B) x 5pcs

#### 6-2. DCC Decoders

Compatible models: All cars

A059, DCC DECODER MULTIPUL TYPE, can be installed in all cars by using mode "B". (See figure 7) A059 (DCC DECODER MULTIPUL TYPE) x 5pcs

\* Please read included instruction manual of A059 for more information.

036-1 and 1036-2	THE IMPERIAL TRA	IN 5CARS SET		
A015 or A059 mode B				
461	330	1	340	460

# 7. Trouble shooting

Check followings before ordering repair.

Problems	Cause	Correction
A train does not run smoothly,	There is dirt on rails.	Remove the dirt with cleaner and cloth.
and lights flicker.	There is dirt on wheels.	Remove the dirt with cleaner and cloth.

# 8. Trouble and repair

- The user is responsible for any trouble, accident, or injury caused by misuse, disassembling, or modification of this product by himself. Rokuhan has no responsibility to repair any product that has been opened. taken apart or modified.
- Specification and appearance of our products are subject to change without prior notice.
- We sell completed product only.
- Take contact Rokuhan customer service if you have any questions about this product.



TOYTEC CORPORATION URL : http://www.rokuhan.com/english/

Opening hour: 10:00 - 12:00, 13:00-17:00 (except Saturday, Sunday, and holidays)

# T036-1 THE IMPERIAL TRAIN LATER MODEL 5CARS SET T036-2 THE IMPERIAL TRAIN INITIAL MODEL 5CARS SET

\* Locomotive (sold separately) is necessary to operate with these cars.

# **Common Instruction manual**

Thank you for purchasing this Rokuhan product.

This product is precision product. Please read this instruction manual carefully before operation and operate properly.

#### 1 Caution

- Please be sure to use only a Rokuhan controller to operate this product.
- Clean track (metal rails) before operation.
- Remove dirt and dust on wheels.
- Do not operate continuously over a long period of time.
- Do not change train direction suddenly. Stop the train first, then change direction.
- In the case of derailment or short circuit, turn off the power at the controller immediately, unplug the controller, and then eliminate the cause of problem.
- Disassembling and modification work could cause failure of this product
- Storing this product under sunlight or fluorescent light for long periods of time could cause fading of body colors.
- Store and operate this product at dry dust free place, keep away from dust, high temperature, humid places.
- To avoid shock or electrocution, do not operate this product in a wet condition or operate with wet hands.
- This product includes small and sharp edged parts. So, please handle with care.
- Please be careful not to cause injury when using tools.
- This product is not recommended for use by children under 15 years old unless supervised by an adult.
- Please make sure to insert cars in plastic bag to avoid any damage when you pack the cars into blister package in book case box.



# 2. Contents



# 3. Tail light

Compatible models: Car No. 460 and 461

Tail light can be switched off. (See figure 1)

 $\label{eq:Please} Please \mbox{ use the following procedure to switch on and off.}$ 



#### 4. Antenna installation

#### 4-1. Installation of Antenna-A

Compatible model: Car No. 340

Please attach two antennas part A. (See figure 2) \* Please pay attention to part's direction.



# 4-2. Installation of Antenna-B

Compatible model: Car No. 330

Please attach two TV antennas part B. (See figure3) \* Please pay attention to parts' direction.







#### 4-4. Installation of Antenna-D

Compatible model: Car No. 1 Please attach one antenna D. (See figure 5 ) .



# 5. Switch to couplers

Arnold couplers are included in this product as default. They can be exchanged other types of couplers (sold separately). (See figure 6)

